

PREFACE

WHAT IS IN THIS GUIDE

This user guide gives you step-by-step instructions on how to install, configure and connect a LaCie 12big Rack Serial 2 system to your host computer system, and how to use and maintain the system.

WHO SHOULD USE THIS GUIDE

This user guide assumes that you have a working knowledge of storage appliance products. If you do not have these skills, or are not confident with the instructions in this guide, do not proceed with the installation.

QUALIFIED PERSONNEL

The personnel referred to within this document are defined as follows:

- Service Person: A person having appropriate technical training and experience necessary to be aware of hazards to which that person may be exposed in performing a task and of measures to minimize the risks to that person or other persons.
- User/Operator: Any person other than a Service Person.

TERMS AND ABBREVIATIONS

CLI	Common Line Interface	PDU	Power Distribution Unit
PSU	Power Supply Unit	EEPROM	Electrically Erasable Programmable Read-Only Memory
RAID	Redundant Arrays of Inexpensive Disks	EM	Enclosure Management
PCM	Power Cooling Module	ESD	Electro-Static Discharge
SAS	Serial Attached SCSI	ESI	Enclosure Services Interface Processor
SATA	Serial ATA	SBB	Storage Bridge Bay
SCSI	Small Computer System Interface	I2C	Inter-Integrated Circuit
SEP	Storage Enclosure Processor	SES	SCSI Enclosure Services
LED	Light-Emitting Diode	SFF	Small Form Factor
UPS	Universal Power Supply	PCB	Printed Circuit Board
VPD	Vital Product Data		