UPLOADING AND DOWNLOADING FILES

When you upload a file to your wireless storage device or network-attached storage device, it is placed in one of the libraries according to its type: Videos, Photos, Music, or Documents.

A file downloaded from the storage device to your mobile device is managed by the operating system.

Note: If you are transferring a large amount of content to your wireless storage device, it is recommended that you connect it directly to a computer rather than using a wireless connection. To learn how to copy content to your storage device using a computer, review the storage device's user manual.

UPLOAD CONTENT FROM YOUR MOBILE DEVICE TO YOUR STORAGE DEVICE

1. ≡

From the home page, tap on **Connectivity** () on the upper left corner. Choose your mobile device from the selection drawer on the left.

- 2. Tap on the folder with the contents you want to upload. For example, **Pictures**.
- 3.

Tap on the **More** icon () on the upper right corner of the app screen and tap **Select item**.

- 4. Tap the items you want to upload to your mobile storage device. A check mark appears on each item that you select.
 - To deselect a single item, tap on it.
 - To select all files in the view, tap on **Select items** on the top left and **Select All**. To undo Select All, tap on **Select items** and **Deselect All**.
- 5. Tap on the **Upload** icon on the upper right corner.

Note: Uploaded files can be viewed within media libraries or the device's folder. To view the folder, go to Files

=

and Folders () and tap on *Product* (*Product* is the name of your storage device). Tap on the device folder, e.g. Tablet. Browse the sub-folders to view the uploaded files.)

DOWNLOAD CONTENT FROM YOUR STORAGE DEVICE TO YOUR MOBILE DEVICE

1.

From the home page, tap on **Connectivity** () on the upper left corner. Choose your library (e.g. Videos or Photos) from the selection drawer on the left.

2.

Tap on the **More** icon () on the upper right corner of the app screen and tap **Select item**.

- 3. Tap the items you want to download to your mobile device. A check mark appears on each item that you select.
 - To deselect a single item, tap on it.
 - To select all files in the view, tap on **Select items** on the top left and **Select All**. To undo Select All, tap on **Select items** and **Deselect All**.
- 4. Tap on the **Download** icon on the upper right corner.