

INTRODUCTION

Welcome to the User Manual for the LaCie RikikiTV. Designed for televisions that feature USB recording, the RikikiTV helps you pause, record, and play your favorite programs. Using your television's onscreen menu, you can schedule recordings or start one on the spot. The RikikiTV is also compatible with audio/video devices that include a USB connector, such as digital TV receivers, Internet TV boxes, Blu-ray players, game systems, media players. For a complete list of compatible devices, please see the [RikikiTV Compatibility List](#).



This manual will help you install your LaCie RikikiTV. Consult the [Getting Help](#) page if you have questions regarding installation and operation.

BOX CONTENT

Your box contains the following:

- LaCie RikikiTV
- Universal television mounting kit
- USB 2.0 cable
- Quick Install Guide (printed on the packaging)

Important info: Please save your packaging. In the event that the drive should need to be repaired or serviced, it must be returned in its original packaging.

MINIMUM SYSTEM REQUIREMENTS

Your system must meet certain requirements in order for your LaCie product to function properly. For a list of these requirements, please refer to the product packaging or consult the product support web page at www.lacie.com/support/.

STATUS LIGHT INFORMATION

Refer to the chart below for details on the status light.

Light Behavior	Status
On, Steady	Drive is on
Flickering	Data access
Off	Drive is off