

LACIE DESKTOP MANAGER



LaCie Desktop Manager is a software utility that provides important information regarding the status and health of your device.

INSTALLING LACIE DESKTOP MANAGER

If LaCie Desktop Manager is not installed on your computer (check your Windows system tray or Mac menu bar), you can install it:

- 1. Double click the Rugged RAID’s volume in Computer (Windows) or on the Desktop (Mac).
- 2. Open the LaCie/Software folder.
- 3. Launch the installer located in the folder for your operating system.

When setup is complete, launch LaCie Desktop Manager from the system tray (Windows) or the menu bar (Mac).

Windows	Mac
	

LaCie Desktop Manager provides a list of all compatible LaCie devices in the left-hand column. If you have more than one compatible LaCie device, choose a product and use the tabs to navigate to the page you want. Options can vary based upon the product.

INFO TAB



Review the details of your device:

- Name
- Model
- Hard drive ID
- Connection type
- Total capacity
- Available capacity

REFORMAT

From the **Info** tab, you can reformat the hard drives.

Caution: Choosing **Reformat** launches your operating system's disk utility (see [Optional Formatting and Partitioning](#) for details). Formatting erases all data stored on your hard drives. To protect files, back up your hard drives before selecting **Reformat**.

STATUS TAB




Review the health of the:

- Hardware
- RAID configuration

You can also enable alerts to receive status updates.

Important info: Activating alerts may affect the transfer rates of your device. For optimal transfer rates, disable alerts.

EMAIL TAB



The screenshot shows the 'Email' tab in the LaCie Desktop Manager application. The window title is 'LaCie Desktop Manager'. The top navigation bar includes 'Info', 'Status', 'Email' (selected), and 'Preferences'. On the left, a sidebar shows 'Rugged RAID' and 'LaCie Rugged RAID' under a blue header. The main content area has a heading 'Enter up to five email addresses to receive notifications regarding your LaCie device.' Below this is the 'Email Address:' section with five input fields labeled 'Email 1:' through 'Email 5:'. The 'Alert notifications:' section has two checked checkboxes: 'Temperature' and 'Disks'.

LaCie Desktop Manager

Info Status **Email** Preferences

Rugged RAID
LaCie Rugged RAID

Enter up to five email addresses to receive notifications regarding your LaCie device.

Email Address:

Email 1:

Email 2:

Email 3:

Email 4:

Email 5:

Alert notifications:

☒ Temperature

☒ Disks

You can enter up to five email addresses to receive messages regarding changes to the status of your LaCie device. You can also enter an email subject line.

Check the boxes to select the events that trigger email alerts.