GETTING CONNECTED

Follow the steps in the order they are given to ensure that the LaCie 2big Thunderbolt 2 volume mounts correctly on your computer. By default, the drives are configured in FAST mode (see <u>Manage RAID</u>) and formatted for Mac (HFS+ journaled).

WINDOWS AND THE LACIE 2BIG

Since the LaCie 2big is preconfigured for Mac, Windows users must clean the hard drives when first connecting the device to the computer. Directions to clean the hard drives can be found below (<u>Windows only - clean the hard drives</u>).

CONNECT THE POWER AND INTERFACE CABLES

1. Remove the side panel to access the interface and power connections. Place one hand on the front of the device for balance and use the other hand to push on the rear of the panel and slide the panel away from the enclosure. **Important:** The side panel may require added pressure to remove it from the slot.



- 2. Connect the included power supply in the following order:
 - 1. The LaCie 2big's power port.
 - 2. An active power outlet.



- 3. Choose a port to connect the LaCie 2big:
 - Thunderbolt 2:

 Mac: Connect the included Thunderbolt technology cable to one of the Thunderbolt ports on the LaCie 2big and a compatible port on your computer. The second Thunderbolt 2 port on the enclosure can be used to daisy chain compatible devices and displays (see <u>Daisy Chain (Thunderbolt 2 only</u>)). The LaCie 2big turns on automatically if your computer is powered on and the volume mounts on the desktop.



- Windows: See <u>Windows: Install the Thunderbolt driver</u> and then <u>Windows: Clean the hard drives</u>. Make certain to clean the hard drives before formatting them for Windows.
- **USB 3.0:** Connect the included USB 3.0 cable to the USB 3.0 port on the LaCie 2big and a compatible port on your computer. USB 3.0 transfer rates are only available when connecting the LaCie 2big to a computer with a USB 3.0 port.
 - Mac: The LaCie 2big turns on automatically if your computer is powered on and the volume mounts on the desktop.
 - Windows: The LaCie 2big turns on automatically if your computer is powered on. Make certain to clean the hard drives before formatting them for Windows. See <u>Windows: Clean the hard drives</u>.
- 4. Replace the side panel to protect the cable connections. **Important:** The side panel may require added pressure to reinsert it into the slot.

Windows: Install Thunderbolt driver

Consider the following before proceeding with the directions below:

- Make certain that your PC has a Thunderbolt technology or Thunderbolt 2 port.
- Your PC may include a driver that recognizes the LaCie 2big Thunderbolt 2. However, LaCie cannot guarantee the same performance or features when using the built-in or default Windows driver rather than the driver provided by LaCie.
 - 1. Download the Thunderbolt driver for the 2big Thunderbolt 2 at the following link: LaCie 2big Thunderbolt 2 downloads.
- 2. Unzip the downloaded file and note where it is located. For example, you can unzip the file on your PC's desktop.
- 3. Go to Start > Control Panel > Device Manager.
- 4. Click **IDE ATA/ATAPI controllers**. Note that there is one item named *Standard AHCI 1.0 Serial ATA Controller*.



5. Connect the 2big Thunderbolt 2 to your PC. Plug one end of the Thunderbolt cable to the LaCie 2big and the other end to a compatible port on your PC. Note that a second item named *Standard AHCI 1.0 Serial ATA Controller* appears in **IDE ATA/ATAPI controllers**.



6. Right click on the second item named Standard AHCI 1.0 Serial ATA Controller and choose Properties.



7. Choose the **Details** tab.

neral Driver	Details Resources		
Standar	d AHCI 1.0 Serial AT.	A Controller	
openy)evice descripti	on		
alue			
Standard AHCI	1.0 Serial ATA Contro	ller	

8. In the pull-down menu, choose **Hardware Ids**.



9. Confirm that the value string includes *1B4B*, *9220* and *00111C19*. If the value does not include the characters demonstrated in the screenshot, close the properties and check the first *Standard AHCI 1.0 Serial ATA Controller* for the string.



10. Right click on the properly identified *Standard AHCI 1.0 Serial ATA Controller* and choose **Update Drive Software**.

🚔 Device Manager		
File Action View Help		
(* +) 🖬 🖾 📓 📾 🕺 😰 😽 🖏		
MININT-FDNS0PD		4
Batteries		
Biometric Devices		
- 📲 Computer		
🗅 👝 Disk drives		
Display adapters		
DVD/CD-ROM drives		
IDE ATA/ATAPI controllers		
-Ca ATA Channel 0		-
-Ca ATA Channel 0		1
- Ca ATA Channel 1		
-Ca ATA Channel 1		
-Ca ATA Channel 2		
ATA Channel 4		
-Ca ATA Channel 5		
ATA Channel o		Li L
Carl Ala Channel /		
Standard AHCI 1.0 Serial ATA Control	er	
Transing devices	Undate Driver Software	
Keyboards	Disable	
Hernory technology driver	Disable	
- Mice and other pointing devices	Uninstall	
Modems	Scan for hardware changes	-
Launches the Update Driver Software Wizard for the s	Properties	

11. Choose **Browse my computer for driver software** and navigate to the driver downloaded in step 1.



12. Choose the folder that applies to your version of Windows and then choose **OK**:

Select the	folder that contains drivers for yo	our hardware.
- 16	2.3.0.1059	
4	Window_Driver	
	🗼 1.2.0.1043-whql	
	amd64	-
	🤑 i386	E
Þ 🌡 A	dobePremierePro8AllTrial.065	
Þ 🔥 D	DISCOVERY_Source	
Folder:	2bigTBT2U3_1.2.0.1043_windo	wsdvrwhql

- 64-bit: Choose amd64.
- 32-bit: Choose **i386**.
- 13. Choose **Next** to confirm the update.
- 14. Device Manager shows that the new driver has been installed.



Go to the next section to clean the hard drives before formatting them.

Windows: Clean the hard drives

Since the hard drives are formatted for Mac (HFS+), all partitions must be erased, including the EFI partition. Windows Disk Management cannot erase the EFI partition so you must run **Diskpart**, a separate Windows utility. For additional information on Diskpart, click <u>here</u>.

Basic 167.68 GB Online	System Reserved 100 MB NTFS Healthy (System, Active, Primary Partitio	(C2) 167.58 GB NTFS Healthy (Boot, Page File, Crash Dump, Primary Partition)				
Disk 1 Basic 476.94 GB Online	200 MB Healthy (EFI System Partition)	476.62 GB Healthy (Primary Partition)	128 MB Healthy (Primary Partition)			
Disk 2 Basic 476.94 GB Online	200 MB Healthy (EFI System Partition)	476.62 GB Healthy (Primary Partition)	128 MB Healthy (Primary Partition)			
DVD (D:) No Media						
Unallocated	Primary partition					

Important info: Cleaning hard drives is data destructive. If you have data on the LaCie 2big, LaCie recommends that you back up all files before following the steps below.

The steps below are illustrated using a standard hard drive enclosure with two hard drives. The images may not represent your product.

- Diskpart will delete and format any hard drive that you select. Therefore, to avoid deleting data on other devices, disconnect all external hard drives from your PC except the LaCie 2big. LaCie is not responsible for lost data. Diskpart cannot delete the System disk.
- 2. Connect the LaCie product to your Windows computer via the included USB 3.0 cable (see <u>Getting Connected</u>). If necessary, turn the device on (see <u>LEDs and LED Power Button</u>).
- 3. Search for and launch **Diskpart**.



4. In the Diskpart prompt, type **list disk**.



5. Make certain to locate the disk number(s) for your LaCie device then type **select disk** *n*. *n* is the number for

the first LaCie hard drive (1 in the screenshot below). If you are uncertain of the disk number for the LaCie product, launch **Disk Management**. You should see the number assigned to the LaCie product.

C:\Windows	system32\diskpart.exe					×	
Microsoft DiskPart version 6.1.7601 Copyright (C) 1999-2008 Microsoft Corporation. On computer: LENOVOEDGE2-PC							
DISKPART> 1	ist disk						
Disk ###	Status	Size	Free	Dyn	Gpt		
Disk Ø Disk 1 Disk 2	Online Foreign Foreign	167 GB 476 GB 476 GB	0 B 0 B 0 B	*			
DISKPART> s	elect disk 1						
						~	

6. Diskpart confirms that your hard disk has been selected.

C:\Windows\system32\diskpart.ex	æ				×
Microsoft DiskPart versio Copyright (C) 1999-2008 M On computer: LENOVOEDGE2-	n 6.1.7601 licrosoft C PC	orporatio	n.		• III
DISKPART> list disk					
Disk ### Status	Size	Free	Dyn	Gpt	
Disk Ø Online Disk 1 Foreign Disk 2 Foreign	167 GB 476 GB 476 GB	0 B 0 B 0 B	*	 	
DISKPART> select disk 1					
Disk 1 is now the selecte	d disk.				
DISKPART>					

7. To delete all partitions on the hard disk, type **clean**.

C:\Windows	system32\diskpart.ex	e				ı x
Microsoft D Copyright (On computer	iskPart versio C> 1999–2008 M : LENOVOEDGE2–3	n 6.1.7601 icrosoft C PC	orporatio	n.		Ê
DISKPART> 1	ist disk					
Disk ###	Status	Size	Free	Dyn	Gpt	
Disk Ø Disk 1 Disk 2	Online Foreign Foreign	167 GB 476 GB 476 GB	0 B 0 B 0 B	*		
DISKPART> s	elect disk 1					
Disk 1 is n	ow the selecte	d disk.				
DISKPART> c	lean					
						+

8. Diskpart confirms that your hard disk is clean, meaning that the partitions have been deleted.



9. The LaCie product is ready to be formatted for your operating system. See <u>Formatting</u> for instructions.

UNMOUNTING THE VOLUME

In order to avoid file system corruption, it is important to unmount the volumes before turning off the enclosure or disconnecting the interface cable. See <u>Unmounting Your Drive</u> for details.