

CUSTOMIZING YOUR STORAGE DEVICE

The media app provides two levels for customizing your storage device: **More** and **Settings**. You can review and change options to suit your needs.

Note: Your storage device might not support all features listed below.

MORE



The **More** icon () is available on the top right of the app's screen. Tap on it see the menu.

- **Refresh:** Refresh the page.
- **Select item:** Select one or more items in a library or folder.
- **Info:** See the percentage of battery charge. Tap on **Advanced** for important network details: Network Name; MAC Address; IP Address; Wi-Fi Channel; and, Security.
- **Help:** Tap on **Help** for tips on how to use your wireless storage.

Note: Certain options may not be available in all views. For example, the More menu has fewer options on the Home page.

SETTINGS



Settings is an option in the **More** menu. Tap on the **More** icon () and tap **Settings**.

▪ Application Settings:

- Tap **Language** to change the language.
- Tap **Download Location** to change the download destination on your mobile device.
- Enable/disable **Stream and Download** by tapping on its checkbox. This option is not available when your storage device is connected to a Wi-Fi network with access to the Internet.
- Enable/disable the **Internal player** by tapping on its checkbox.
- Enable/disable the **Remote Video Pre-Buffer** by tapping on its checkbox.
- Tap on **Clear cache** to empty the cache.

▪ Server Settings:

- Tap **Change name** to change the name of the storage device.
- Tap **Enable password** to prevent unauthorized access to the storage device. You will be prompted to enter a password. Make certain to note the password as you will be required to enter it when logging on to your mobile device.
- Tap **Change password** to change the current password for the storage device. You must enable a password to use this option.
- Tap **ECO mode** to enable/disable power conservation. Doing so will help to increase battery life. See the Help section [Conserving Battery Life](#).

- Tap **Rebuild database** to initiate a scan of the storage device. The scan attempts to find and rebuild data that can cause errors. A prompt will ask you to confirm the rebuild.
- Tap **Reset the device's settings** to restore the storage device to its factory default.
- Tap **Restart** to reboot the storage device.
- Tap **Shut Down** to power off the storage device.
- **Cloud Storage:** Synchronize content on your storage device with your Dropbox or Google Drive accounts. Tip: Your storage device must be connected to the Internet to access this feature. Google Drive is not available on all storage devices.
- **Report a problem:** Send an email to report a problem with the media app.
- **About:** Tap to review: versions of the media app and your storage device; the number of users connected to the storage device; and, capacity (total, used, and available).
- **About (Advanced info):** **Advanced** info is an option in **About**. Tap **Advanced** info to review important network details: Network Name; MAC Address; IP Address; Wi-Fi Channel; and, Security.